

Tableau de conversion Pression - couple

Pression : Couple

Clé Hydraulique **STEALTH 2**

PSI : Bars Newton mètre

Cartouche à oeil hexagonale



Réglez la pression hydraulique en PSI ou en BAR sur votre pompe.
Vous obtiendrez les couples correspondants sur la clé.

1000	70	254
1200.....	84.....	302
1400.....	98.....	353
1600.....	110.....	403
1800.....	124.....	456
2000	138	508
2200.....	152.....	559
2400.....	165.....	610
2600.....	179.....	661
2800.....	193.....	712
3000	207	763
3200.....	220.....	814
3400.....	234.....	865
3600.....	248.....	915
3800.....	262.....	966
4000	276	1017
4200.....	290.....	1067
4400.....	303.....	1118
4600.....	317.....	1169
4800.....	331.....	1219
5000	345	1270
5200.....	358.....	1320
5400.....	372.....	1371
5600.....	386.....	1421
5800.....	400.....	1471
6000	414	1521
6200.....	427.....	1572
6400.....	441.....	1623
6600.....	455.....	1675
6800.....	468.....	1726
7000	482	1777
7200.....	496.....	1827
7400.....	510.....	1877
7600.....	524.....	1927
7800.....	538.....	1977
8000	552	2027
8200.....	565.....	2077
8400.....	579.....	2128
8600.....	593.....	2179
8800.....	607.....	2229
9000	620	2280
9200.....	634.....	2331
9400.....	648.....	2382
9600.....	662.....	2432
9800.....	676.....	2483
10000	690	2534

www.hytorc-services.com

Tableau de conversion Pression - couple

Pression : Couple

Clé Hydraulique **STEALTH 4**

PSI : Bars Newton mètre

Cartouche à œil hexagonale



Réglez la pression hydraulique en PSI ou en BAR sur votre pompe. Vous obtiendrez les couples correspondants sur la clé.

1000	70	546
1200.....	84.....	655
1400.....	98.....	764
1600.....	110.....	874
1800.....	124.....	983
2000	138	1093
2200.....	152.....	1200
2400.....	165.....	1307
2600.....	179.....	1414
2800.....	193.....	1521
3000	207	1628
3200.....	220.....	1737
3400.....	234.....	1846
3600.....	248.....	1954
3800.....	262.....	2063
4000	276	2172
4200.....	290.....	2278
4400.....	303.....	2384
4600.....	317.....	2490
4800.....	331.....	2596
5000	345	2702
5200.....	358.....	2813
5400.....	372.....	2925
5600.....	386.....	3036
5800.....	400.....	3147
6000	414	3259
6200.....	427.....	3369
6400.....	441.....	3478
6600.....	455.....	3588
6800.....	468.....	3698
7000	482	3808
7200.....	496.....	3913
7400.....	510.....	4019
7600.....	524.....	4124
7800.....	538.....	4230
8000	552	4335
8200.....	565.....	4446
8400.....	579.....	4558
8600.....	593.....	4669
8800.....	607.....	4780
9000	620	4891
9200.....	634.....	5003
9400.....	648.....	5114
9600.....	662.....	5226
9800.....	676.....	5338
10000	690	5450

www.hytorc-services.com

Tableau de conversion Pression - couple

Pression : Couple

Clé Hydraulique **STEALTH 8**

PSI : Bars Newton mètre

Cartouche à œil hexagonale



Réglez la pression hydraulique en PSI ou en BAR sur votre pompe. Vous obtiendrez les couples correspondants sur la clé.

1000	70	1083
1200.....	84.....	1300
1400.....	98.....	1517
1600.....	110.....	1730
1800.....	124.....	1939
2000	138	2149
2200.....	152.....	2363
2400.....	165.....	2578
2600.....	179.....	2792
2800.....	193.....	3006
3000	207	3221
3200.....	220.....	3442
3400.....	234.....	3663
3600.....	248.....	3884
3800.....	262.....	4105
4000	276	4326
4200.....	290.....	4547
4400.....	303.....	4768
4600.....	317.....	4989
4800.....	331.....	5211
5000	345	5432
5200.....	358.....	5656
5400.....	372.....	5879
5600.....	386.....	6103
5800.....	400.....	6327
6000	414	6550
6200.....	427.....	6762
6400.....	441.....	6974
6600.....	455.....	7186
6800.....	468.....	7398
7000	482	7610
7200.....	496.....	7825
7400.....	510.....	8040
7600.....	524.....	8255
7800.....	538.....	8470
8000	552	8685
8200.....	565.....	8900
8400.....	579.....	9114
8600.....	593.....	9328
8800.....	607.....	9542
9000	620	9756
9200.....	634.....	9970
9400.....	648.....	10183
9600.....	662.....	10396
9800.....	676.....	10610
10000	690	10823

www.hytorc-services.com

Tableau de conversion Pression - couple

Pression : Couple

Clé Hydraulique **STEALTH 14**

PSI : Bars Newton mètre

Cartouche à œil hexagonale



Réglez la pression hydraulique en PSI ou en BAR sur votre pompe.

Vous obtiendrez les couples correspondants sur la clé.

1000	70	1903
1200.....	84.....	2283
1400.....	98.....	2664
1600.....	110.....	3047
1800.....	124.....	3433
2000	138	3819
2200.....	152.....	4205
2400.....	165.....	4590
2600.....	179.....	4976
2800.....	193.....	5362
3000	207	5748
3200.....	220.....	6134
3400.....	234.....	6520
3600.....	248.....	6906
3800.....	262.....	7292
4000	276	7678
4200.....	290.....	8063
4400.....	303.....	8449
4600.....	317.....	8834
4800.....	331.....	9219
5000	345	9604
5200.....	358.....	9993
5400.....	372.....	10382
5600.....	386.....	10771
5800.....	400.....	11160
6000	414	11548
6200.....	427.....	11936
6400.....	441.....	12324
6600.....	455.....	12711
6800.....	468.....	13099
7000	482	13487
7200.....	496.....	13878
7400.....	510.....	14268
7600.....	524.....	14659
7800.....	538.....	15050
8000	552	15440
8200.....	565.....	15828
8400.....	579.....	16216
8600.....	593.....	16603
8800.....	607.....	16991
9000	620	17379
9200.....	634.....	17768
9400.....	648.....	18157
9600.....	662.....	18546
9800.....	676.....	18935
10000	690	19324

www.hytorc-services.com